



# Correct installation of the 40x40x10 fan with M3x12mm screws



**1**

Place the Fan on a flat surface. It will help with the nut insertion as some pressure is required.



**2**

Place the nut over the placeholder, as shown above. Make sure the corners are aligned. Insert the remaining 3 screws.



**3**

With a screwdriver, push the nut firmly into the placeholder all the way to the bottom. Repeat for the remaining screws. You can use 2 or all 4.



**4**

The nut sits now at the bottom of the placeholder and will be about 3mm in.



**5**

Insert the Mx12mm screw from the bottom of the fan hat, as shown above. Screw in 2-3 mm until the head touches the hat.



**6**

The M3x12mm screw is barely visible and does not protrude. Repeat for the remaining screws.